

Kyocera TASKalfa 205c/255c & 255/305 Copiers – Meter read how to

System Menu Settings

System Menu include;

Item	Description	Reference Page
<i>Quick Setup Wizard</i>	The Quick Setup Wizard configures fax, cassette, and Energy Saver settings.	3-25
<i>Language</i>	Select the language displayed on the touch panel.	9-5
<i>Report</i>	Print reports to check the machine settings and status. Default settings for printing the result reports can also be configured.	9-5
<i>Counter</i>	This counts the number of pages printed or scanned.	3-11

To print the total page count, perform the following steps

- 1.) Press the **System Menu** button
- 2.) Select the option for **Reports**
- 3.) Select **Status Page**
- 4.) Confirm print by pressing **OK**

Report

Print reports to check the machine settings and status. Default settings for printing the result reports can also be configured.

Report Print

Item	Description
Status Page	<p>Prints the status page, allowing you to check the information including current settings, available memory space, and optional equipment installed.</p> 