


Checking Counter



Press the **Counter** key to check the number of sheets printed and scanned.

Printed Pages				
	Copy	Printer	FAX	Total
Black&White:	300	600	100	1000
Full Color:	200	500	100	800
SingleColor:	100	100	0	200
Total:	600	1200	200	2000


Scanned Pages				
	Copy	FAX	Others	Total
Originals:	600	200	1000	1800

Buttons: Print Status Page, Printed Pages by Paper Size, Close

For details, refer to *Checking and Printing Counter* on page 10-33.

Help Screen

If you have difficulty operating the machine, you can check how to operate it using the touch panel.



To show the Help screen, press the **Help** key on the operation panel. The Help screen shows explanations of functions and how to use them.

Help Screen Display

Help titles — Points to the yellow title bar.

Displays information about functions and machine operation. — Points to the main text area.

Show the screen of the tab that includes the function explained in Help. (In the case of this screen, the screen that appears after step 1 of *Setting Procedure* is performed will appear.) — Points to the 'Try It' button.

Displays the Help list. — Points to the 'Display List' button.

Scrolls up and down by pressing [^] or [v] when the help text cannot be displayed in its entirety on a single screen. — Points to the up and down navigation arrows.

Closes the Help screen and returns to the original screen. — Points to the 'End' button.