


Checking Counter



Press the **Counter** key to check the number of sheets printed and scanned.

Printed Pages				
Copy	Printer	FAX	Total	
Black&White:	300	600	100	1000

Scanned Pages				
Copy	FAX	Others	Total	
Originals:	600	200	1000	1800


Status 10/10/2010 10:10

For details, refer to *Checking and Printing Counter* on page 10-33.

3

Help Screen

If you have difficulty operating the machine, you can check how to operate it using the touch panel.



To show the Help screen, press the **Help** key on the operation panel. The Help screen shows explanations of functions and how to use them.

Help Screen Display

Help titles — Selecting Paper Source

Displays information about functions and machine operation.

Shows the screen of the tab that includes the function explained in Help. (In the case of this screen, the screen that appears after step 1 of *Setting Procedure* is performed will appear.)

Scrolls up and down by pressing [^] or [v] when the help text cannot be displayed in its entirety on a single screen.

Displays the Help list.

Closes the Help screen and returns to the original screen.

Setting Procedure
 1. Press [Org./Paper/Finishing].
 2. Press [Paper Selection].

Try It Display List End

Status 10/10/2010 10:10